

If you are installing a Hilo for the very first time, or are experiencing creaking from your Hilo 2-bolt-style head, follow the instructions below.

- 1) You can leave the post on the bike, including leaving the cable attached, or remove the post from the bike as shown.



- 2) Remove saddle from post



- 3) Clean rails on saddle and clamps which hold the saddle with rubbing alcohol to remove any dirt build up.



- 4) Align clamps properly, so all of the "X" marks will come together on the same side when the saddle is installed.



5) Install saddle so cable housing faces the back of the saddle.



6) Grease threads on both bolts, including top and bottom of washer. Apply liberally and wipe off later.



- 7) Hand tighten the bolts evenly, each bolt a little bit at a time until the saddle is level, and then use a torque wrench to torque bolts to 50 in/lbs or 6.5 n/m.



*Do not turn one bolt more than one complete revolution without turning the other bolt similarly. It will cause an imbalance and more stress on one bolt or clamp versus evenly distributing the load over both clamps and bolts